


Screen inversion

RR420 has its display inversed compared to RR400, but both devices share the same program. After the first update of the RR420 program, if the screen is upside down, tell the system that the screen needs to be inversed.

Enter the main menu and press in the upper right corner (there is no button):



Check in the checkbox at the bottom right of the screen that opens:



Validate and get out with return button at bottom right corner then restart the system (power interruption).

For the welcome screen, install an inverted image as indicated in the last § of the manual. We can find the original image on the website:

<http://www.crisartech.fr/download/prg/190109/logo.png>